




Accy's	Description	Boost Pumps	Description	Engine Pumps	Description
1211175-007	Actuator, Variable Stator	5006003B	Pumping Unit Assembly	708600-1	Engine Driven Pump
1211175-010	Actuator, Variable Stator	5006003C	Pumping Unit Assembly	708600-2	Engine Driven Pump
1211175-011	Actuator, Variable Stator	5006003D	Pumping Unit Assembly	708600-5	Engine Driven Pump
1211313-010	Actuator, Variable Stator	5006286A	Pumping Unit Assembly	708600-6	Engine Driven Pump
125334	Crossfeed Valve, Fuel	5006286B	Pumping Unit Assembly	708600-7	Engine Driven Pump
125334-1	Crossfeed Valve, Fuel	5006286C	Pumping Unit Assembly	714900-1	Engine Driven Pump
125334D	Crossfeed Valve, Fuel	5006286D	Pumping Unit Assembly	714900-2	Engine Driven Pump
125334D-1	Crossfeed Valve, Fuel	5006286E	Pumping Unit Assembly	714900-3	Engine Driven Pump
125334D-2	Crossfeed Valve, Fuel	5006286F	Pumping Unit Assembly	714900-4	Engine Driven Pump
40884-1	Valve (Refuel)	5006286G	Pumping Unit Assembly	714900-5	Engine Driven Pump
40884-23	Valve (Refuel)	568-1-26713-001	Pump, Fuel Boost	723301-10	Engine Driven Pump
40884-3	Valve (Refuel)	568-1-26713-002	Pump, Fuel Boost	723301-11	Engine Driven Pump
40884-4	Valve (Refuel)	568-1-26713-003	Pump, Fuel Boost	723301-12	Engine Driven Pump
40884-44	Valve (Refuel)	568-1-26713-004	Pump, Fuel Boost	724400-1	Engine Driven Pump
40884-6	Valve (Refuel)	568-1-26713-005	Pump, Fuel Boost	724400-2	Engine Driven Pump
40884-7	Valve (Refuel)	568-1-27202-002	Pump, Fuel Boost	825501-10	Engine Driven Pump
40885-1	Control Unit (Refuel)	568-1-27202-005	Pump, Fuel Boost	825501-12	Engine Driven Pump
40885-2	Control Unit (Refuel)	568-1-27202-006	Pump, Fuel Boost	828300-1	Engine Driven Pump
40885-4	Control Unit (Refuel)	568-1-27202-007	Pump, Fuel Boost	828300-2	Engine Driven Pump
40885-5	Control Unit (Refuel)	568-1-27202-02R	Pump, Fuel Boost	828300-3	Engine Driven Pump
40885-7	Control Unit (Refuel)	568-1-27202-05R	Pump, Fuel Boost	828300-4	Engine Driven Pump
40885-10	Control Unit (Refuel)	568-1-29117-002	Pump, Fuel Boost	828300-5	Engine Driven Pump
40885-22	Control Unit (Refuel)	568-1-29117-003	Pump, Fuel Boost	9255-03	Engine Driven Pump
		60-755100-2	Pump, Fuel Boost	9255-04	Engine Driven Pump
		60-755100-4	Pump, Fuel Boost	9255-05	Engine Driven Pump
		60-755100-5	Pump, Fuel Boost	9255-06	Engine Driven Pump
		60-72101-4	Pump, Fuel Boost	9255-07	Engine Driven Pump
		60-72101-5	Pump, Fuel Boost	9255-08	Engine Driven Pump
		60-98976-1	Motor Impeller Sub Assembly	9255-09	Engine Driven Pump
		60-98976-2	Motor Impeller Sub Assembly	9257-01	Engine Driven Pump
		60-98976-4	Motor Impeller Sub Assembly	9257-02	Engine Driven Pump
		60-98976-6	Motor Impeller Sub Assembly	9257-03	Engine Driven Pump
		60-989100-2	Motor Impeller Sub Assembly	9257-04	Engine Driven Pump
		60-989100-4	Motor Impeller Sub Assembly	9257-05	Engine Driven Pump
		60-989100-5	Motor Impeller Sub Assembly	9257-06	Engine Driven Pump
				9257-07	Engine Driven Pump
				9257-08	Engine Driven Pump
				9297-01A3	Engine Driven Pump
				9297-01A4	Engine Driven Pump
				9297-01A5	Engine Driven Pump
				9297-01A6	Engine Driven Pump
				5006834D	Engine Driven Pump
				5006834E	Engine Driven Pump
				5006834F	Engine Driven Pump
				5006834G	Engine Driven Pump
				5006834H	Engine Driven Pump
				5006834J	Engine Driven Pump
				5006834K	Engine Driven Pump
				5006834L	Engine Driven Pump
				5006834M	Engine Driven Pump
				5009913B	Engine Driven Pump
				5009913C	Engine Driven Pump
				5009913D	Engine Driven Pump




Accy's	Description	Boost Pumps	Description	Engine Pumps	Description
				5009913E	Engine Driven Pump
				5009913F	Engine Driven Pump
				5009913G	Engine Driven Pump
				5010216B	Engine Driven Pump
				5010216C	Engine Driven Pump
				5010216D	Engine Driven Pump
				5010216E	Engine Driven Pump
				5010216F	Engine Driven Pump
				5010216G	Engine Driven Pump
				5010224	Engine Driven Pump
				5010224A	Engine Driven Pump
				GP202MK1	Engine Driven Pump




Item	Part Number	Component Description	Manufacturer	ATA
1	025277	Pump, Rotary (L1011)	Hamilton Sundstrand	49-31-01
2	107728A	Motor, Actuator	ITT	28-09-14
3	107796A	Actuator Assy.	ITT	28-09-10
4	107970	Valve, Fuel	ITT	28-09-12
5	112-507	Housing Assy, Scroll	Sundstrand	28-24-02
6	112-508	Pump, Fuel Boost	Sundstrand	28-24-03
7	112-509	Valve, Check	Sundstrand	28-24-04
8	1140	Fuel Level Measuring Stick	Kaiser Electroprecision	28-40-1
9	1211175	Actuator, Variable Stator	Arkwin Industries	75-32-11
10	1211175	Actuator, Variable Stator	Arkwin Industries	75-32-15
11	1211313	Actuator, Variable Stator	Arkwin Industries	75-32-13
12	124536	Fuel Control Unit (APU)	Garrett	49-30-01
13	125120	Valve, Fuel	ITT	28-09-12
14	125272	Centrifugal Pump	Sundstrand	28-24-01
15	125334	Valve, Fuel	ITT	28-09-12
16	125334D	Valve, Body Assembly	ITT	28-25-14
17	130595	Valve, Mech. Shut off	Whittaker	28-3-1
18	138412	Valve	Whittaker	28-22-01
19	139525	Pressure Poppet Relief Valve	Whittaker	28-21-01
20	139595	Valve Assy	Whittaker	28-25-04
21	139725	Valve, Rotary Actuator Shut off	Whittaker	28-22-01
22	139735	Valve, Rotary Actuator Shut off	Whittaker	28-25-04
23	139755	Valve, Rotary Actuator Shut off	Whittaker	28-22-01
24	139775	Valve, Rotary Actuator Shut off	Whittaker	28-22-01
25	139785	Valve, Rotary Actuator Shut off	Whittaker	28-21-03
26	139905	Valve, Rotary Actuator Shut off	Whittaker	28-22-01
27	156130	Actuator Assy.	Whittaker	28-21-04
28	16P138-1	Pressure Actuator Relief Valve	Allen Aircraft	28-21-05
29	20217 (743496)	Valve Solenoid	Valve Research	73-00-00
30	2052C	Booster Pump	Intertechnique	28-09-01
31	230555	Valve, Jettison Shut off	Whittaker	28-31-01
32	230905	Valve, Rotary Actuator Shut off	Whittaker	28-22-01
33	234125	Pressure Poppet Relief Valve	Whittaker	28-21-01
34	243600	Pump, Main Engine Fuel	Argo-Tech	73-11-1
35	2524994	Fuel Control- APU	Aviation Electric	49-31-02
36	2670136	Control Valve	Parker	28-20-01
37	2670137	Control Valve	Parker	20-20-01
38	2830007	Valve, Shutoff	Parker	28-20-30
39	311900	Valve, Fuel Dump	HR Textron	28-10-18
40	3244761	Fuel Control- APU	Aviation Electric	49-31-02
41	3244768	Fuel Control- APU	Allied Signal	73-20-22
42	358200	Pump, Main Engine Fuel	Argo-Tech	73-11-1
43	3602310	Fuel Control Unit	Allied Signal	49-30-49
44	3603100	Fuel Control Unit, APU	Allied Signal	49-30-50
45	3603879	Valve & Flow Divider Assy	Allied Signal	49-31-08
46	3607680	Accel. Control (APU Timer Head)	Allied Signal	49-31-19
47	3608000	Fuel Control Unit, APU	Allied Signal	49-31-17




Item	Part Number	Component Description	Manufacturer	ATA
48	3609150	Fuel Control Unit, APU	Allied Signal	49-30-69
49	3617750	Fuel Control Unit, APU	Honeywell	49-31-83
50	3715	Actuator Assy.	General Design	28-20-01
51	371900	Pump, Main Engine Fuel	Argo-Tech	73-11-1
52	373401	Pump, Main Fuel	Argo-Tech	73-11-1
53	378200	Pump, Main Engine Fuel	Argo-Tech	73-11-1
54	382400	Pump, Main Fuel	Argo-Tech	73-11-1
55	384300	Pump, Main Fuel	Argo-Tech	73-11-2
56	3876046	Solenoid Valve Assy	Garrett	49-31-15
57	3882550	Flow Divider/Drain Valve	Honeywell	49-31-63
58	3882639	Fuel Check Valve	Garrett	49-31-59
59	389400	Pump, Main Fuel	Argo-Tech	73-11-1
60	40574	Actuator	JC Carter	28-20-01
61	40575	Actuator	JC Carter	28-20-03
62	40884	Valve	JC Carter	28-20-05
63	40884	Valve	JC Carter	28-23-53
64	40885	Control Unit (Refuel)	JC Carter	28-20-30
65	40885	Control Unit (Refuel)	JC Carter	28-20-32
66	442187	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
67	446469	Fuel Heater	Pratt & Whitney	73-14-01
68	474815	Fuel Heater	Pratt & Whitney	73-14-01
69	491018	Oil Cooler	Pratt & Whitney	73-22-01
70	492110	Oil Cooler	Pratt & Whitney	73-22-01
71	499527	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
72	5006002	Main Fuel Boost Pump	Hamilton Sundstrand	28-22-01
73	5006003	Pumping Unit Assembly	Hamilton Sundstrand	28-22-02
74	5006005	Housing Unit Assembly	Hamilton Sundstrand	28-22-03
75	5006150	Discharge Check Valve Assy	Hamilton Sundstrand	28-22-04
76	5006151	Motive Flow & Screen Valve Assy	Hamilton Sundstrand	28-22-05
77	5006283	Override Fuel Boost Pump	Hamilton Sundstrand	28-22-11
78	5006286	Pumping Unit Assembly	Hamilton Sundstrand	28-22-12
79	5006834	Fuel Gear Pump	Hamilton Sundstrand	73-11-12
80	5007246	Fuel Pump	Hamilton Sundstrand	73-11-03
81	5009913	LP/HP Fuel Pumps	Hamilton Sundstrand	73-18-41
82	5010216	LP/HP Fuel Pumps	Hamilton Sundstrand	73-18-42
83	5010224	Fuel Pump	Hamilton Sundstrand	73-11-03
84	502938	Fuel Heater	Pratt & Whitney	73-14-01
85	522649	Fuel Heater	Pratt & Whitney	73-14-01
86	522829	Fuel Heater	Pratt & Whitney	73-14-01
87	534096	Oil Cooler	Pratt & Whitney	73-22-01
88	548003	Oil Cooler	Pratt & Whitney	73-22-01
89	567219	Oil Cooler	Pratt & Whitney	73-22-01
90	568-1-26713	Pump, Fuel Boost	GEC Marconi	28-20-37
91	568-1-27202	Pump, Fuel Boost	GEC Marconi	28-21-51
92	568-1-29117	Pump, Fuel, Override/Jettison	Eaton	28-20-44
93	583500	Fuel Control, Jet	Hamilton Standard	73-21-1




Item	Part Number	Component Description	Manufacturer	ATA
94	60007-1	Refuel Overpress Reg & Adapter	JC Carter	28-20-22
95	60160	Pressure Fueling Shut-off Valve	JC Carter	28-20-05
96	60213	Pressure Fueling Receptacle	JC Carter	28-20-06
97	60-70303	Pump, Fuel Boost	Hydro-Aire	28-31-05
98	60-70306	Pump, Fuel Boost	Hydro-Aire	28-31-05
99	60-70307	Pump, Fuel Boost	Hydro-Aire	28-31-05
100	60-70308	Pump, Fuel Boost	Hydro-Aire	28-31-05
101	60-70309	Pump, Fuel Boost	Hydro-Aire	28-31-05
102	60-703103	Pump, Fuel Boost	Hydro-Aire	28-31-05
103	60-703104	Pump, Fuel Boost	Hydro-Aire	28-31-05
104	60-703113	Pump, Fuel Boost	Hydro-Aire	28-31-05
105	60-72101	Pump, Fuel Boost	Hydro-Aire	28-31-02
106	60-72101	Pump, Fuel Boost	Hydro-Aire	28-31-03
107	60-72301	Pump, Fuel Boost	Hydro-Aire	28-31-02
108	60-72301	Pump, Fuel Boost	Hydro-Aire	28-31-05
109	60-75501	Fuel Boost Pump	Hydro-Aire	28-22-06
110	60-75503	Fuel Boost Pump	Hydro-Aire	28-22-06
111	60-75504	Fuel Boost Pump	Hydro-Aire	28-22-06
112	60-755100	Fuel Boost Pump	Hydro-Aire	28-22-06
113	60-755100	Fuel Boost Pump	Hydro-Aire	28-22-08
114	60-847	Pump, Fuel Boost	Hydro-Aire	28-22-03
115	60-98902	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-04
116	60-98904	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-04
117	60-98906	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-04
118	60-98908	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-05
119	60-98976	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-04
120	60-98976	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-07
121	60-989100	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-05
122	60-989100	Motor Impeller Sub-Assembly	Crane Hydro-Aire	28-22-09
123	612600	Fuel Heater	Pratt & Whitney	73-14-01
124	614350	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
125	64-1119	Pump, Fuel Boost	GEC-Marconi	73-10-3
126	646526	Fuel Heater	Pratt & Whitney	73-14-01
127	65-5094	Pump, Fuel Boost	Nash/GEC Plessey	28-20-1
128	65-5095	Pump, Fuel Boost	Nash/GEC Plessey	28-20-1
129	654233	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
130	664203	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
131	674358	Fuel Heater	Pratt & Whitney	73-14-01
132	6867	Refuel Overpress Reg & Adapter	JC Carter	28-20-22
133	692545 (V5000)	Valve, Solenoid Shut-Off	Allied Signal	49-30-67
134	704073	Fuel Heater	Pratt & Whitney	73-14-01
135	704300	Fuel Control, Jet	Hamilton Standard	73-11-11
136	705300	Pump, Main Fuel	Argo-Tech	73-11-1
137	705400	Pump, Main Fuel	Argo-Tech	73-11-1
138	705500	Pump, Main Fuel	Argo-Tech	73-11-1
139	706800	Pump, Main Fuel	Argo-Tech	73-11-1




Item	Part Number	Component Description	Manufacturer	ATA
140	706920	Fuel Heater	Pratt & Whitney	73-14-01
141	707658	Fuel Control, Jet	Hamilton Standard	73-21-1
142	708300	Fuel Control, Jet	Hamilton Standard	73-11-11
143	708400	Fuel Pump	Argo-Tech	73-11-12
144	708600	Fuel Control, Jet	Hamilton Standard	73-11-11
145	710110	Fuel Control, Jet	Hamilton Standard	73-21-1
146	710077	Fuel Control, Jet	Hamilton Standard	73-21-1
147	710777	Fuel Control, Jet	Hamilton Standard	73-21-2
148	711000	Pump, Fuel	Argo-Tech	73-11-04
149	711283	Fuel Control, Jet	Hamilton Standard	73-2-2
150	711286	Fuel Control, Jet	Hamilton Standard	73-2-2
151	711287	Fuel Control, Jet	Hamilton Standard	73-2-3
152	711659	Fuel Heater	Pratt & Whitney	73-14-01
153	714810	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
154	714900	Fuel Pump	Argo-Tech	73-11-13
155	715000	Pump, Main Fuel	Argo-Tech	73-11-1
156	718142	Fuel Heater	Pratt & Whitney	73-14-01
157	718800	Pump, Fuel	Argo-Tech	73-11-04
158	720050	Fuel Control, Jet	Hamilton Standard	73-21-2
159	720100	Pump, Fuel	Argo-Tech	73-11-04
160	720300	Pump, Fuel	Argo-Tech	73-11-04
161	720389	Fuel Control, Jet	Hamilton Standard	73-2-2
162	720398	Fuel Control, Jet	Hamilton Standard	73-2-2
163	720399	Fuel Control, Jet	Hamilton Standard	73-2-3
164	721000	Pump, Fuel	Argo-Tech	73-11-04
165	722100	Pump, Fuel	Argo-Tech	73-11-04
166	723300	Pump, Fuel	Argo-Tech	73-11-05
167	724400	Fuel Pump	Argo-Tech	73-11-14
168	726218	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
169	731229	Fuel Heater	Pratt & Whitney	73-14-01
170	734467	Fuel Heater	Pratt & Whitney	73-14-01
171	736802	Fuel Heater	Pratt & Whitney	73-14-01
172	737062	Fuel Heater	Pratt & Whitney	73-14-01
173	738200	Valve, Fuel Transfer Float	H.R. Textron	28-27-01
174	739400	Fuel Level Control Switch	H.R. Textron	28-21-04
175	739666	Fuel Control, Jet	Hamilton Standard	73-21-2
176	742511	Fuel Control, Jet	Hamilton Standard	73-21-2
177	742522	Fuel Control, Jet	Hamilton Standard	73-21-2
178	743602	Fuel Control, Jet	Hamilton Standard	73-21-2
179	743801	Fuel Control, Jet	Hamilton Standard	73-21-1
180	743802	Fuel Control, Jet	Hamilton Standard	73-21-1
181	743803	Fuel Control, Jet	Hamilton Standard	73-21-1
182	745608	Fuel Heater	Pratt & Whitney	73-14-01
183	746529	Fuel Heater	Pratt & Whitney	73-14-01
184	749965	Oil Cooler	Pratt & Whitney	73-22-01
185	752137	Fuel Heater	Pratt & Whitney	73-14-01



Item	Part Number	Component Description	Manufacturer	ATA
186	755280	Fuel Heater	Pratt & Whitney	73-14-01
187	758847	Fuel Heater	Pratt & Whitney	73-14-01
188	766342	Valve, Fuel Pressurizing and Dump	Pratt & Whitney	73-12-01
189	769606	Fuel Control Unit	Hamilton Standard	73-21-05
190	772969	Fuel Heater	Pratt & Whitney	73-14-01
191	772997	Fuel Heater	Pratt & Whitney	73-14-01
192	782267	Fuel Heater	Pratt & Whitney	73-14-01
193	786445	Fuel Heater	Pratt & Whitney	73-14-01
194	789644	Fuel Heater	Pratt & Whitney	73-14-01
195	789762	Fuel Heater	Pratt & Whitney	73-14-01
196	791288	Fuel Heater	Pratt & Whitney	73-14-01
197	80111	Fuel Shut-off Valve	JC Carter	28-20-1
198	821249	Fuel Pump	Pratt & Whitney/Argo-Tech	73-11-1
199	821250	Fuel Pump	Pratt & Whitney/Argo-Tech	73-11-2
200	825500	Pump, Fuel	Argo-Tech	73-11-04
201	828300	Fuel Pump	Argo-Tech	73-11-15
202	835800	Fuel Pump	Argo-Tech	73-11-1
203	835900	Fuel Pump	Argo-Tech	73-11-2
204	899727	Pump, Power Rotary	Allied Signal	49-31-01
205	9255	Pump	Chandler Evans	73-12-04
206	9257	Pump	Chandler Evans	73-12-04
207	9295	Main Fuel Pump	Goodrich	73-16-02
208	9297	Main Fuel Pump	Goodrich	73-16-02
209	9452	Main Fuel Pump	Chandler Evans	73-1-1
210	9455	Main Fuel Pump	Chandler Evans	73-1-1
211	9470	Main Fuel Pump	Chandler Evans	73-1-1
212	9477	Pump, Main Fuel	Chandler Evens	73-1-1
213	9478	Pump, Main Fuel	Chandler Evens	73-1-1
214	966595	Valve & Flow Divider Assy	Allied Signal	49-31-08
215	968870	Valve & Flow Divider Assy	Allied Signal	49-31-08
216	969900	Fuel Control Assembly	Allied Signal	49-32-01
217	AV16A1323B	Valve Shut-off	ITT	28-22-01
218	AV16A1323B1	Valve Shut-off	ITT	28-22-01
219	AV16A1348B	Valve Shut-off	ITT	28-22-01
220	AV16B1736D	Valve, Fuel Gate	ITT	28-1-1
221	AV16E1261D	Valve, Fuel Gate	ITT	28-22-02
222	EM487	Actuator Assy.	Vickers Electro	28-20-21
223	PAC101	Pump and Control	Lucas	73-10-01
224	PAC102	Pump and Control	Lucas	73-10-06
225	V3400-283 (743496)	Solenoid Valve	Valcor Eng	73-20-01
226	V3400-292 (769606)	Solenoid Valve	Valcor Eng	73-20-02
227	V5000-40 (692545)	Solenoid Shut-off Valve	Allied Signal	49-30-67
228	V5000-43 (692545)	Solenoid Shut-off Valve	Allied Signal	49-30-67



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
1	025277-100-01	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
2	025277-100-02	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
3	025277-100-03	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
4	025277-100-08	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
5	025277-100-09	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
6	025277-100-10	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
7	025277-200-02	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
8	025277-200-03	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
9	025277-200-09	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
10	025277-200-10	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
11	025277-300-01	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
12	025277-300-02	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
13	025277-300-03	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
14	025277-300-04	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
15	025277-300-05	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
16	025277-300-06	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
17	025277-300-07	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
18	025277-300-08	Rotary Pump (L1011)	Hamilton Sunstrand	116	49-31-01
19	106785A104	Motor Assembly	ITT	171	24-09-02
20	107728A100	Actuator Motor	ITT	29	28-09-14
21	107728A122	Actuator Motor	ITT	29	28-09-14
22	107728A125	Actuator Motor	ITT	29	28-09-14
23	107796A108	Actuator Assembly	ITT	30	28-09-10
24	107796A110	Actuator Assembly	ITT	30	28-09-10
25	107796A115	Actuator Assembly	ITT	30	28-09-10
26	107970	Fuel Valve	ITT	42	28-09-12
27	107970-1	Fuel Valve	ITT	42	28-09-12
28	112-507-02	Scroll Housing Assembly	Sundstrand	89	28-24-02
29	112-507-03	Scroll Housing Assembly	Sundstrand	89	28-24-02
30	112-507-04	Scroll Housing Assembly	Sundstrand	89	28-24-02
31	112-508-02	Pump and Motor Assembly	Hamilton Sundstrand	33	28-24-03
32	112-508-03	Pump and Motor Assembly	Hamilton Sundstrand	33	28-24-03
33	112-508-04	Pump and Motor Assembly	Sundstrand	33	28-24-03
34	112-508-05	Pump and Motor Assembly	Hamilton Sundstrand	33	28-24-03
35	112-508-06	Pump and Motor Assembly	Sundstrand	33	28-24-03
36	112-509-02	Check Valve	Sundstrand	34	28-24-04
37	1140-0014	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
38	1140-0024	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
39	1140-0034	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
40	1140-0044	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
41	1140-0054	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
42	1140-0064	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
43	1140-0074	Fuel Level Measuring Stick	Kaiser Electroprecision	36	28-40-1
44	1211175-007	Variable Stator Actuator	Arkwin Industries	220	75-32-11
45	1211175-010	Variable Stator Actuator	Arkwin Industries	220	75-32-11
46	1211175-011	Variable Stator Actuator	Arkwin Industries	220	75-32-11
47	1211175-018	Variable Stator Actuator	Arkwin Industries	305	75-32-15
48	1211313-010	Variable Stator Actuator	Arkwin Industries	202	75-32-13



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
49	124536-18-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
50	124536-19-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
51	124536-20-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
52	124536-22-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
53	124536-23-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
54	124536-25-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
55	124536-27-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
56	124536-30-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
57	124536-32-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
58	124536-33-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
59	124536-34-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
60	124536-35-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
61	124536-37-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
62	124536-38-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
63	124536-39-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
64	124536-5-1	Fuel Control Unit (APU)	Garrett	41	49-30-01
65	125120	Fuel Valve	ITT	42	28-09-12
66	125120-1	Fuel Valve	ITT	42	28-09-12
67	125334	Fuel Valve	ITT	42	28-09-12
68	125334-1	Fuel Valve	ITT	42	28-09-12
69	125334D	Valve Body Assembly	ITT	188	28-25-14
70	125334D-1	Valve Body Assembly	ITT	188	28-25-14
71	130595	Mechanic Shut Off Valve	Whittaker	43	28-3-1
72	138412-4	Valve	Whittaker	45	28-22-01
73	138412-5	Valve	Whittaker	45	28-22-01
74	138412-6	Valve	Whittaker	45	28-22-01
75	139525	Pressure Poppet Relief Valve	Whittaker	143	28-21-01
76	139595	Valve Assembly	Whittaker	85	28-25-04
77	139725	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
78	139725-1	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
79	139735-1	Rotary Actuator Shutoff Valve	Whittaker	85	28-25-04
80	139755	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
81	139755-1	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
82	139755-2	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
83	139775	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
84	139775-1	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
85	139785	Rotary Actuator Shutoff Valve	Whittaker	44	28-21-03
86	139785-1	Rotary Actuator Shutoff Valve	Whittaker	44	28-21-03
87	139785-2	Rotary Actuator Shutoff Valve	Whittaker	44	28-21-03
88	139905	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
89	139905-1	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
90	156130-3	Actuator Assembly	Whittaker	46	28-21-04
91	156130-4	Actuator Assembly	Whittaker	46	28-21-04
92	156130-5	Actuator Assembly	Whittaker	46	28-21-04
93	156130-8	Actuator Assembly	Whittaker	46	28-21-04
94	156130-9	Actuator Assembly	Whittaker	46	28-21-04
95	16P138-1	Pressure Actuator Relief Valve	Allen Aircraft	158	28-21-05



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
96	20217-8 (743496-8)	Valve Solenoid	Valve Research	194	73-00-00
97	20217-9 (743496-9)	Valve Solenoid	Valve Research	194	73-00-00
98	2052C08	Booster Pump	Intertechnique	156	28-09-01
99	2052C09	Booster Pump	Intertechnique	156	28-09-01
100	2052C20	Booster Pump	Intertechnique	156	28-09-01
101	2052C21	Booster Pump	Intertechnique	156	28-09-01
102	2052C22	Booster Pump	Intertechnique	156	28-09-01
103	2052C23	Booster Pump	Intertechnique	156	28-09-01
104	230555	Jettison Shutoff Valve	Whittaker	48	28-31-01
105	230905	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
106	230905-01	Rotary Actuator Shutoff Valve	Whittaker	45	28-22-01
107	234125	Pressure Poppet Relief Valve	Whittaker	143	28-21-01
108	243600	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
109	243601-26	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
110	243601-27	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
111	243601-28	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
112	243601-29	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
113	243601-30	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
114	243601-31	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
115	243601-32	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
116	243601-33	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
117	243601-34	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
118	243601-35	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
119	243601-36	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
120	2524994-10	Fuel Control (APU)	Aviation Electric	135	49-31-02
121	2524994-11	Fuel Control (APU)	Aviation Electric	135	49-31-02
122	2524994-4	Fuel Control (APU)	Aviation Electric	135	49-31-02
123	2524994-6	Fuel Control (APU)	Aviation Electric	135	49-31-02
124	2524994-7	Fuel Control (APU)	Aviation Electric	135	49-31-02
125	2524994-8	Fuel Control (APU)	Aviation Electric	135	49-31-02
126	2524994-9	Fuel Control (APU)	Aviation Electric	135	49-31-02
127	2670136	Control Valve	Parker	142	28-20-01
128	2670137-101	Control Valve	Parker	142	28-20-01
129	2830007-101	Float Operated Shut-off Valve	Parker Hannifin	252	28-20-30
130	311900-1	Fuel Valve Dump	HR Textron	110	28-10-18
131	3244761-2	Fuel Control (APU)	Aviation Electric	135	49-31-02
132	3244761-3	Fuel Control (APU)	Aviation Electric	135	49-31-02
133	3244761-5	Fuel Control (APU)	Aviation Electric	135	49-31-02
134	3244761-6	Fuel Control (APU)	Aviation Electric	135	49-31-02
135	3244761-7	Fuel Control (APU)	Aviation Electric	135	49-31-02
136	3244768-1	Fuel Control (APU)	Allied Signal	136	73-20-22
137	3244768-10	Fuel Control (APU)	Allied Signal	136	73-20-22
138	3244768-11	Fuel Control (APU)	Allied Signal	136	73-20-22
139	3244768-12	Fuel Control (APU)	Allied Signal	136	73-20-22
140	3244768-2	Fuel Control (APU)	Allied Signal	136	73-20-22
141	3244768-3	Fuel Control (APU)	Allied Signal	136	73-20-22
142	3244768-4	Fuel Control (APU)	Allied Signal	136	73-20-22



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
143	3244768-5	Fuel Control (APU)	Allied Signal	136	73-20-22
144	3244768-6	Fuel Control (APU)	Allied Signal	136	73-20-22
145	3244768-7	Fuel Control (APU)	Allied Signal	136	73-20-22
146	3244768-8	Fuel Control (APU)	Allied Signal	136	73-20-22
147	3244768-9	Fuel Control (APU)	Allied Signal	136	73-20-22
148	3360	Actuator Assembly	JC Carter	172	28-20-03
149	358200	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
150	358201	Main Fuel Gear Pump	Argo-Tech/DELTA	127	73-11-1
151	358201-26	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
152	358201-27	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
153	358201-28	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
154	358201-29	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
155	358201-30	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
156	358201-31	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
157	358201-32	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
158	358201-33	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
159	358201-34	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
160	358201-35	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
161	358201-36	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
162	3602310-1	Fuel Control Unit	Allied-Signal	51	49-30-49
163	3602310-13	Fuel Control Unit	Allied-Signal	51	49-30-49
164	3602310-14	Fuel Control Unit	Allied-Signal	51	49-30-49
165	3602310-15	Fuel Control Unit	Allied-Signal	51	49-30-49
166	3602310-16	Fuel Control Unit	Allied-Signal	51	49-30-49
167	3602310-17	Fuel Control Unit	Allied-Signal	51	49-30-49
168	3602310-18	Fuel Control Unit	Allied-Signal	51	49-30-49
169	3602310-19	Fuel Control Unit	Allied-Signal	51	49-30-49
170	3602310-2	Fuel Control Unit	Allied-Signal	51	49-30-49
171	3602310-20	Fuel Control Unit	Allied-Signal	51	49-30-49
172	3602310-21	Fuel Control Unit	Allied-Signal	51	49-30-49
173	3602310-22	Fuel Control Unit	Allied-Signal	51	49-30-49
174	3602310-23	Fuel Control Unit	Allied-Signal	51	49-30-49
175	3602310-24	Fuel Control Unit	Allied-Signal	51	49-30-49
176	3602310-25	Fuel Control Unit	Allied-Signal	51	49-30-49
177	3602310-26	Fuel Control Unit	Allied-Signal	51	49-30-49
178	3602310-27	Fuel Control Unit	Allied-Signal	51	49-30-49
179	3602310-28	Fuel Control Unit	Allied-Signal	51	49-30-49
180	3602310-29	Fuel Control Unit	Allied-Signal	51	49-30-49
181	3602310-3	Fuel Control Unit	Allied-Signal	51	49-30-49
182	3602310-30	Fuel Control Unit	Allied-Signal	51	49-30-49
183	3602310-31	Fuel Control Unit	Allied-Signal	51	49-30-49
184	3602310-32	Fuel Control Unit	Allied-Signal	51	49-30-49
185	3602310-33	Fuel Control Unit	Allied-Signal	51	49-30-49
186	3602310-34	Fuel Control Unit	Allied-Signal	51	49-30-49
187	3602310-35	Fuel Control Unit	Allied-Signal	51	49-30-49
188	3602310-36	Fuel Control Unit	Allied-Signal	51	49-30-49
189	3602310-37	Fuel Control Unit	Allied-Signal	51	49-30-49




ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
190	3602310-4	Fuel Control Unit	Allied-Signal	51	49-30-49
191	3602310-5	Fuel Control Unit	Allied-Signal	51	49-30-49
192	3602310-6	Fuel Control Unit	Allied-Signal	51	49-30-49
193	3602310-7	Fuel Control Unit	Allied-Signal	51	49-30-49
194	3602310-8	Fuel Control Unit	Allied-Signal	51	49-30-49
195	3603100-1	Fuel Control Unit (APU)	Allied-Signal	100	49-30-50
196	3603100-1-1	Fuel Control Unit (APU)	Allied-Signal	101	49-30-51
197	3603100-4	Fuel Control Unit (APU)	Allied-Signal	100	49-30-50
198	3603100-6	Fuel Control Unit (APU)	Allied-Signal	100	49-30-50
199	3603100-7	Fuel Control Unit (APU)	Allied-Signal	100	49-30-50
200	3603879-1-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
201	3603879-2-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
202	3607680-5	Accel. Control (APU Timer Head)	Allied-Signal	92	49-31-19
203	3607680-6	Accel. Control (APU Timer Head)	Allied-Signal	92	49-31-19
204	3607680-7	Accel. Control (APU Timer Head)	Allied-Signal	92	49-31-19
205	3607680-8	Accel. Control (APU Timer Head)	Allied-Signal	92	49-31-19
206	3607680-9	Accel. Control (APU Timer Head)	Allied-Signal	92	49-31-19
207	3608000-10	Fuel Control Unit (APU)	Allied-Signal	99	49-31-17
208	3608000-2	Fuel Control Unit (APU)	Allied-Signal	99	49-31-17
209	3608000-4	Fuel Control Unit (APU)	Allied-Signal	99	49-31-17
210	3608000-6	Fuel Control Unit (APU)	Allied-Signal	99	49-31-17
211	3609150-1-1	Fuel Control Unit (APU)	Honeywell	88	49-30-69
212	3609150-2	Fuel Control Unit (APU)	Honeywell	88	49-30-69
213	3609150-3-1	Fuel Control Unit (APU)	Honeywell	88	49-30-69
214	3609150-4	Fuel Control Unit (APU)	Honeywell	88	49-30-69
215	3609150-5	Fuel Control Unit (APU)	Honeywell	88	49-30-69
216	3609150-8	Fuel Control Unit (APU)	Honeywell	88	49-30-69
217	3617750-1	Fuel Control Unit (APU)	Honeywell	170	49-31-83
218	3617750-2	Fuel Control Unit (APU)	Honeywell	170	49-31-83
219	3617750-3	Fuel Control Unit (APU)	Honeywell	170	49-31-83
220	3617750-4	Fuel Control Unit (APU)	Honeywell	170	49-31-83
221	3715	Actuator Assembly	General Design	174	28-20-01
222	371900	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
223	371901-26	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
224	371901-27	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
225	371901-28	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
226	371901-29	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
227	371901-30	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
228	371901-31	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
229	371901-32	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
230	371901-33	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
231	371901-34	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
232	371901-34	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
233	371901-35	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
234	371901-36	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
235	373401-26	Fuel Pump	Argo-Tech	264	73-11-01
236	373401-27	Fuel Pump	Argo-Tech	264	73-11-01




ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
237	373401-28	Fuel Pump	Argo-Tech	264	73-11-01
238	373401-29	Fuel Pump	Argo-Tech	264	73-11-01
239	373401-30	Fuel Pump	Argo-Tech	264	73-11-01
240	373401-32	Fuel Pump	Argo-Tech	264	73-11-01
241	373401-34	Fuel Pump	Argo-Tech	264	73-11-01
242	373401-36	Fuel Pump	Argo-Tech	264	73-11-01
243	373401-37	Fuel Pump	Argo-Tech	264	73-11-01
244	378200	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
245	378201-10	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
246	378201-11	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
247	378201-12	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
248	378201-13	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
249	378201-15	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
250	378201-3	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
251	378201-4	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
252	378201-5	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
253	378201-6	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
254	378201-7	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
255	378201-8	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
256	378201-9	Main Engine Fuel Pump	Argo-Tech	94	73-11-1
257	382401-26	Fuel Pump	Argo-Tech	264	73-11-01
258	382401-27	Fuel Pump	Argo-Tech	264	73-11-01
259	382401-28	Fuel Pump	Argo-Tech	264	73-11-01
260	382401-29	Fuel Pump	Argo-Tech	264	73-11-01
261	382401-30	Fuel Pump	Argo-Tech	264	73-11-01
262	382401-32	Fuel Pump	Argo-Tech	264	73-11-01
263	382401-34	Fuel Pump	Argo-Tech	264	73-11-01
264	382401-36	Fuel Pump	Argo-Tech	264	73-11-01
265	382401-37	Fuel Pump	Argo-Tech	264	73-11-01
266	384300 (P & W P/N 736808)	Main Fuel Pump	Argo-Tech	102	73-11-2
267	384301-10	Main Fuel Pump	Argo-Tech	102	73-11-2
268	384301-2	Main Fuel Pump	Argo-Tech	102	73-11-2
269	384301-3	Main Fuel Pump	Argo-Tech	102	73-11-2
270	384301-4	Main Fuel Pump	Argo-Tech	102	73-11-2
271	384301-5	Main Fuel Pump	Argo-Tech	102	73-11-2
272	384301-6	Main Fuel Pump	Argo-Tech	102	73-11-2
273	384301-7	Main Fuel Pump	Argo-Tech	102	73-11-2
274	384301-8	Main Fuel Pump	Argo-Tech	102	73-11-2
275	3876046-4	Solenoid Valve Assembly	Allied Signal	176	49-31-15
276	3882550-1	Flow Divider/Drain Valve	Honeywell	160	49-31-63
277	3882550-2	Flow Divider/Drain Valve	Honeywell	160	49-31-63
278	3882550-3	Flow Divider/Drain Valve	Honeywell	160	49-31-63
279	3882639	Fuel Check Valve	Garrett	165	49-31-59
280	3882639-1	Fuel Check Valve	Garrett	165	49-31-59
281	3882639-2	Fuel Check Valve	Garrett	165	49-31-59
282	3882639-3	Fuel Check Valve	Garrett	165	49-31-59
283	3882639-4	Fuel Check Valve	Garrett	165	49-31-59



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
284	3882639-5	Fuel Check Valve	Garrett	165	49-31-59
285	389401-26	Fuel Pump	Argo-Tech	264	73-11-01
286	389401-27	Fuel Pump	Argo-Tech	264	73-11-01
287	389401-28	Fuel Pump	Argo-Tech	264	73-11-01
288	389401-29	Fuel Pump	Argo-Tech	264	73-11-01
289	389401-30	Fuel Pump	Argo-Tech	264	73-11-01
290	389401-32	Fuel Pump	Argo-Tech	264	73-11-01
291	389401-34	Fuel Pump	Argo-Tech	264	73-11-01
292	389401-36	Fuel Pump	Argo-Tech	264	73-11-01
293	389401-37	Fuel Pump	Argo-Tech	264	73-11-01
294	391001-643	Liquid Quantity Transmitter	Simmonds	53	28-41-15
295	391001-644	Liquid Quantity Transmitter	Simmonds	53	28-41-15
296	391001-645	Liquid Quantity Transmitter	Simmonds	53	28-41-15
297	391001-646	Liquid Quantity Transmitter	Simmonds	53	28-41-15
298	391001-647	Liquid Quantity Transmitter	Simmonds	53	28-41-15
299	391001-648	Liquid Quantity Transmitter	Simmonds	53	28-41-15
300	391001-649	Liquid Quantity Transmitter	Simmonds	53	28-41-15
301	391001-650	Liquid Quantity Transmitter	Simmonds	53	28-41-15
302	391001-651	Liquid Quantity Transmitter	Simmonds	53	28-41-15
303	391001-652	Liquid Quantity Transmitter	Simmonds	53	28-41-15
304	391001-653	Liquid Quantity Transmitter	Simmonds	53	28-41-15
305	391001-654	Liquid Quantity Transmitter	Simmonds	53	28-41-15
306	391001-655	Liquid Quantity Transmitter	Simmonds	53	28-41-15
307	391001-656	Liquid Quantity Transmitter	Simmonds	53	28-41-15
308	391001-657	Liquid Quantity Transmitter	Simmonds	53	28-41-15
309	391041	Liquid Quantity Transmitter	Simmonds/DELTA	120	28-40-25
310	40574 (3715)	Actuator Assembly	JC Carter	174	28-20-01
311	40574-2 (3715-7)	Actuator Assembly	JC Carter	174	28-20-01
312	40574-4	Actuator Assembly	JC Carter	60	28-20-33
313	40884	Valve	JC Carter	106	28-20-05
314	40884-1	Valve	Eaton Aerospace	294	28-23-53
315	40884-23	Valve	Eaton Aerospace	294	28-23-53
316	40884-3	Valve	Eaton Aerospace	294	28-23-53
317	40884-4	Valve Unit	Eaton Aerospace	294	28-23-53
318	40884-44	Valve Unit	Eaton Aerospace	294	28-23-53
319	40884-6	Valve Unit	Eaton Aerospace	294	28-23-53
320	40884-7	Valve Unit	Eaton Aerospace	294	28-23-53
321	40885	Control Unit (Refuel)	JC Carter	90	28-20-32
322	40885	Control Unit (Refuel)	J.C. Carter/DELTA	91	28-20-32
323	40885-10	Control Unit (Refuel)	JC Carter	90	28-20-32
324	40885-2	Control Unit (Refuel)	JC Carter	90	28-20-32
325	40885-22	Control Unit (Refuel)	JC Carter	90	28-20-32
326	40885-4	Control Unit (Refuel)	JC Carter	90	28-20-32
327	40885-5	Control Unit (Refuel)	JC Carter	141	28-20-30
328	40885-5,-7	Control Unit (Refuel)	JC Carter/DELTA	189	28-20-30
329	40885-7	Control Unit (Refuel)	JC Carter	141	28-20-30
330	442187 (774203)	Pressurizing & Dump Fuel Valve	Pratt & Whitney	215	73-12-01



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
331	446469 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
332	474815 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
333	491018 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
334	492110 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
335	499527 (774203)	Pressurizing & Dump Fuel Valve	Pratt & Whitney	215	73-12-01
336	5006002	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
337	5006002A	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
338	5006002B	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
339	5006002C	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
340	5006002D	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
341	5006002E	Main Fuel Boost Pump	Hamilton Sundstrand	146	28-22-01
342	5006003B	Pumping Unit Assembly	Hamilton Sundstrand	163	28-22-02
343	5006003C	Pumping Unit Assembly	Hamilton Sundstrand	163	28-22-02
344	5006003D	Pumping Unit Assembly	Hamilton Sundstrand	163	28-22-02
345	5006005	Housing Unit Assembly	Hamilton Sundstrand	164	28-22-03
346	5006005A	Housing Unit Assembly	Hamilton Sundstrand	164	28-22-03
347	5006005B	Housing Unit Assembly	Hamilton Sundstrand	164	28-22-03
348	5006005C	Housing Unit Assembly	Hamilton Sundstrand	164	28-22-03
349	5006005E	Housing Unit Assembly	Hamilton Sundstrand	164	28-22-03
350	5006150	Discharge Check Valve Assembly	Hamilton Sundstrand	167	28-22-04
351	5006150A	Discharge Check Valve Assembly	Hamilton Sundstrand	167	28-22-04
352	5006151	Motive Flow & Screen Valve Assembly	Hamilton Sundstrand	187	28-22-05
353	5006151A	Motive Flow & Screen Valve Assembly	Hamilton Sundstrand	187	28-22-05
354	5006283	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
355	5006283A	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
356	5006283B	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
357	5006283C	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
358	5006283D	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
359	5006283E	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
360	5006283F	Override Fuel Boost Pump	Hamilton Sundstrand	154	28-22-11
361	5006286	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
362	5006286A	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
363	5006286B	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
364	5006286C	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
365	5006286D	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
366	5006286E	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
367	5006286F	Pumping Unit Assembly	Hamilton Sundstrand	153	28-22-12
368	5006834D	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
369	5006834E	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
370	5006834F	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
371	5006834G	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
372	5006834H	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
373	5006834J	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
374	5006834K	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
375	5006834L	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
376	5006834M	Fuel Gear Pump	Hamilton Sundstrand	253	73-11-12
377	5007246A	Fuel Pump	Hamilton Sundstrand	303	73-11-03



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
378	5007246B	Fuel Pump	Hamilton Sundstrand	303	73-11-03
379	5009913B	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
380	5009913C	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
381	5009913D	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
382	5009913E	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
383	5009913F	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
384	5009913G	LP/HP Fuel Pump	Hamilton Sundstrand	218	73-18-41
385	5010216B	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
386	5010216C	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
387	5010216D	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
388	5010216E	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
389	5010216F	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
390	5010216G	LP/HP Fuel Pump	Hamilton Sundstrand	239	73-18-42
391	5010224	Fuel Pump	Hamilton Sundstrand	303	73-11-03
392	5010224A	Fuel Pump	Hamilton Sundstrand	303	73-11-03
393	502938 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
394	522649 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
395	522829 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
396	534096 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
397	548003 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
398	567219 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
399	568-1-26713-001	Fuel Boost Pump	GEC Marconi	61	28-20-37
400	568-1-26713-002	Fuel Boost Pump	GEC Marconi	61	28-20-37
401	568-1-26713-003	Fuel Boost Pump	GEC Marconi	61	28-20-37
402	568-1-26713-004	Fuel Boost Pump	GEC Marconi	61	28-20-37
403	568-1-26713-005	Fuel Boost Pump	GEC Marconi	61	28-20-37
404	568-1-27202-002	Fuel Pump	GEC Marconi	238	28-21-51
405	568-1-27202-005	Fuel Pump	GEC Marconi	238	28-21-51
406	568-1-27202-02R	Fuel Pump	GEC Marconi	238	28-21-51
407	568-1-27202-05R	Fuel Pump	GEC Marconi	238	28-21-51
408	568-1-29117-002	Fuel Pump, Override/Jettison	Eaton Aerospace	321	28-20-44
409	568-1-29117-003	Fuel Pump, Override/Jettison	Eaton Aerospace	321	28-20-44
410	583500	Fuel Control, Jet	Hamilton Standard	122	73-21-1
411	60007-1	Refuel Overpress Reg & Adapter	JC Carter	108	28-20-22
412	60160	Pressure Fueling Shutoff Valve	JC Carter	106	28-20-05
413	60213-1	Pressure Fueling Receptacle	JC Carter	62	28-23-68
414	60213-10	Pressure Fueling Receptacle	JC Carter	62	28-23-68
415	60213-13	Pressure Fueling Receptacle	JC Carter	62	28-23-68
416	60213-14	Pressure Fueling Receptacle	JC Carter	62	28-23-68
417	60213-17	Pressure Fueling Receptacle	JC Carter	62	28-23-68
418	60213-18	Pressure Fueling Receptacle	JC Carter	62	28-23-68
419	60213-2	Pressure Fueling Receptacle	JC Carter	62	28-23-68
420	60213-9	Pressure Fueling Receptacle	JC Carter	62	28-23-68
421	60-70303 (Boeing P/N 60B92603-3)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
422	60-70303-3 (Boeing P/N 60B92603-303)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
423	60-70306 (Boeing P/N 60B92603-7)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
424	60-70306-1 (Boeing P/N 60B92603-107)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	200	28-31-05



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
425	60-70306-3 (Boeing P/N 60B92603-307)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
426	60-70307 (Boeing P/N 60B92603-9)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
427	60-70307-3 (Boeing P/N 60B92603-309)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
428	60-70308 (Boeing P/N 60B92603-10)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
429	60-70308-3 (Boeing P/N 60B92603-310)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
430	60-70309 (Boeing P/N 60B92603-11)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
431	60-70309-3 (Boeing P/N 60B92603-311)	Fuel Jettison Pump	Crane Hydro-Aire	200	28-31-05
432	60-703103 (Boeing P/N 60B92603-13)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
433	60-703103-3 (Boeing P/N 60B92603-313)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
434	60-703104 (Boeing P/N 60B92603-14)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
435	60-703104-3 (Boeing P/N 60B92603-314)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
436	60-703113 (Boeing P/N 60B92603-15)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
437	60-703113-1 (Boeing P/N 60B92603-115)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	200	28-31-05
438	60-703113-3 (Boeing P/N 60B92603-315)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
439	60-72101 (Boeing P/N 60B92603-17)	Fuel Boost Pump	Crane Hydro-Aire	64	28-31-02
440	60-72101-1 (Boeing P/N 60B92603-22)	Fuel Boost Pump	Crane Hydro-Aire	64	28-31-02
441	60-72101-2 (Boeing P/N 60B92603-23)	Fuel Boost Pump	Crane Hydro-Aire	67	28-31-03
442	60-72101-3 (Boeing P/N 60B92603-317)	Fuel Boost Pump	Crane Hydro-Aire	64	28-31-02
443	60-72101-3A (Boeing P/N 60B92603-322)	Fuel Boost Pump	Crane Hydro-Aire	64	28-31-02
444	60-72101-3B (Boeing P/N 60B92603-24)	Fuel Boost Pump	Crane Hydro-Aire	67	28-31-03
445	60-72101-4 (Boeing P/N 60B92603-26)	Fuel Boost Pump	Crane Hydro-Aire	67	28-31-03
446	60-72101-5 (Boeing P/N 60B92603-25)	Fuel Boost Pump	Crane Hydro-Aire	67	28-31-03
447	60-72301 (Boeing P/N 60B92603-18)	Fuel Boost Pump	Crane Hydro-Aire	64	28-31-02
448	60-72301 (Boeing P/N 60B92603-18)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	200	28-31-05
449	60-72301-3 (Boeing P/N 60B92603-318)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
450	60-72301-4 (Boeing P/N 60B92603-418)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
451	60-72301-5 (Boeing P/N 60B92603-420)	Fuel Jettison Pump Motor Impeller	Crane Hydro-Aire	200	28-31-05
452	60-75501 (Boeing P/N 60B92404-3)	Fuel Boost Pump	Crane Hydro-Aire	65	28-22-06
453	60-75501-1 (Boeing P/N 60B92404-103)	Fuel Boost Pump	Crane Hydro-Aire	65	28-22-06
454	60-75501-4 (Boeing P/N 60B92404-403)	Motor Impeller	Crane Hydro-Aire	65	28-22-06
455	60-75501-5 (Boeing P/N 60B92404-405)	Motor Impeller	Crane Hydro-Aire	65	28-22-06
456	60-75503 (Boeing P/N 60B92404-4)	Motor Impeller	Crane Hydro-Aire	65	28-22-06
457	60-75503-1 (Boeing P/N 60B92404-104)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	65	28-22-06
458	60-75503-4 (Boeing P/N 60B92404-404)	Motor Impeller	Crane Hydro-Aire	65	28-22-06
459	60-75503-5 (Boeing P/N 60B92404-406)	Motor Impeller	Crane Hydro-Aire	65	28-22-06
460	60-75504 (Boeing P/N 60B92404-5)	Fuel Boost Pump	Crane Hydro-Aire	65	28-22-06
461	60-755100 (Boeing P/N 60B92404-6)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	65	28-22-06
462	60-755100-2 (Boeing P/N 60B92404-7)	Fuel Boost Pump	Crane Hydro-Aire	190	28-22-08
463	60-755100-4 (Boeing P/N 60B92404-8)	Fuel Boost Pump	Crane Hydro-Aire	190	28-22-08
464	60-755100-5 (Boeing P/N 60B92404-10)	Fuel Boost Pump	Crane Hydro-Aire	190	28-22-08
465	60-847-1A	Fuel Boost Pump	Crane Hydro-Aire	115	28-22-03
466	60-847-2	Fuel Boost Pump	Crane Hydro-Aire	115	28-22-03
467	60-847-3	Fuel Boost Pump	Crane Hydro-Aire	115	28-22-03
468	60-847-4	Fuel Boost Pump	Crane Hydro-Aire	115	28-22-03
469	60-98902 (Boeing P/N 60B89004-2)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
470	60-98902A (Boeing P/N 60B89004-21)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
471	60-98904 (Boeing P/N 60B89004-4)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
472	60-98904A (Boeing P/N 60B89004-41)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
473	60-98906 (Boeing P/N 60B89004-6)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
474	60-98906A (Boeing P/N 60B89004-61)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
475	60-98908 (Boeing P/N 60B89004-8)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	273	28-22-05
476	60-989100 (Boeing P/N 60B89004-10)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	273	28-22-05
477	60-989100-2 (Boeing P/N 60B89004-12)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	274	28-22-09
478	60-989100-4 (Boeing P/N 60B89004-14)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	274	28-22-09
479	60-989100-5 (Boeing P/N 60B89004-16)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	274	28-22-09
480	60-98976 (Boeing P/N 60B89004-9)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
481	60-98976-1 (Boeing P/N 60B89004-11)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	197	28-22-04
482	60-98976-2 (Boeing P/N 60B89004-13)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	199	28-22-07
483	60-98976-4 (Boeing P/N 60B89004-15)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	199	28-22-07
484	60-98976-5 (Boeing P/N 60B89004-17)	Motor Impeller Sub-Assembly	Crane Hydro-Aire	199	28-22-07
485	612600 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
486	614350 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
487	64-1119-2	Fuel Boost Pump	GEC-Marconi	69	73-10-3
488	64-1119-3	Fuel Boost Pump	GEC-Marconi	69	73-10-3
489	64-1119-4	Fuel Boost Pump	GEC-Marconi	69	73-10-3
490	64-1119-5	Fuel Boost Pump	GEC-Marconi	69	73-10-3
491	646526 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
492	654233 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
493	664203 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
494	674358 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
495	6867	Refuel Overpress Reg & Adapter	JC Carter	108	28-20-22
496	692545-1(V5000-40)	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
497	692545-10	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
498	692545-11	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
499	692545-12	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
500	692545-13	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
501	692545-14	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
502	692545-17	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
503	692545-2	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
504	692545-3(V5000-43)	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
505	692545-400	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
506	692545-500	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
507	692545-6	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
508	692545-7	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
509	692545-9	Solenoid Shut-Off Valve	Allied-Signal	93	49-30-67
510	704073 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
511	704300-1	Fuel Control, Jet	Hamilton Standard	118	73-11-11
512	704300-10	Fuel Control, Jet	Hamilton Standard	118	73-11-11
513	704300-11	Fuel Control, Jet	Hamilton Standard	118	73-11-11
514	704300-12	Fuel Control, Jet	Hamilton Standard	118	73-11-11
515	704300-13	Fuel Control, Jet	Hamilton Standard	118	73-11-11
516	704300-2	Fuel Control, Jet	Hamilton Standard	118	73-11-11
517	704300-3	Fuel Control, Jet	Hamilton Standard	118	73-11-11
518	704300-4	Fuel Control, Jet	Hamilton Standard	118	73-11-11




ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
519	704300-5	Fuel Control, Jet	Hamilton Standard	118	73-11-11
520	704300-6	Fuel Control, Jet	Hamilton Standard	118	73-11-11
521	704300-8	Fuel Control, Jet	Hamilton Standard	118	73-11-11
522	704300-9	Fuel Control, Jet	Hamilton Standard	118	73-11-11
523	705301-26	Fuel Pump	Argo-Tech	264	73-11-01
524	705301-26	Fuel Pump	Argo-Tech	264	73-11-01
525	705301-27	Fuel Pump	Argo-Tech	264	73-11-01
526	705301-28	Fuel Pump	Argo-Tech	264	73-11-01
527	705301-29	Fuel Pump	Argo-Tech	264	73-11-01
528	705301-30	Fuel Pump	Argo-Tech	264	73-11-01
529	705301-32	Fuel Pump	Argo-Tech	264	73-11-01
530	705301-34	Fuel Pump	Argo-Tech	264	73-11-01
531	705301-36	Fuel Pump	Argo-Tech	264	73-11-01
532	705301-37	Fuel Pump	Argo-Tech	264	73-11-01
533	705401-26	Fuel Pump	Argo-Tech	264	73-11-01
534	705401-27	Fuel Pump	Argo-Tech	264	73-11-01
535	705401-28	Fuel Pump	Argo-Tech	264	73-11-01
536	705401-29	Fuel Pump	Argo-Tech	264	73-11-01
537	705401-30	Fuel Pump	Argo-Tech	264	73-11-01
538	705401-32	Fuel Pump	Argo-Tech	264	73-11-01
539	705401-34	Fuel Pump	Argo-Tech	264	73-11-01
540	705401-36	Fuel Pump	Argo-Tech	264	73-11-01
541	705401-37	Fuel Pump	Argo-Tech	264	73-11-01
542	705501-26	Fuel Pump	Argo-Tech	264	73-11-01
543	705501-27	Fuel Pump	Argo-Tech	264	73-11-01
544	705501-28	Fuel Pump	Argo-Tech	264	73-11-01
545	705501-29	Fuel Pump	Argo-Tech	264	73-11-01
546	705501-30	Fuel Pump	Argo-Tech	264	73-11-01
547	705501-32	Fuel Pump	Argo-Tech	264	73-11-01
548	705501-34	Fuel Pump	Argo-Tech	264	73-11-01
549	705501-36	Fuel Pump	Argo-Tech	264	73-11-01
550	705501-37	Fuel Pump	Argo-Tech	264	73-11-01
551	706800	Fuel Pump	Argo-Tech	264	73-11-01
552	706801-29	Fuel Pump	Argo-Tech	264	73-11-01
553	706801-30	Fuel Pump	Argo-Tech	264	73-11-01
554	706801-31	Fuel Pump	Argo-Tech	264	73-11-01
555	706801-32	Fuel Pump	Argo-Tech	264	73-11-01
556	706801-33	Fuel Pump	Argo-Tech	264	73-11-01
557	706801-34	Fuel Pump	Argo-Tech	264	73-11-01
558	706801-35	Fuel Pump	Argo-Tech	264	73-11-01
559	706801-36	Fuel Pump	Argo-Tech	264	73-11-01
560	706801-37	Fuel Pump	Argo-Tech	264	73-11-01
561	706920 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
562	707658	Fuel Control, Jet	Hamilton Standard	122	73-21-1
563	708300-1	Fuel Control, Jet	Hamilton Standard	118	73-11-11
564	708300-2	Fuel Control, Jet	Hamilton Standard	118	73-11-11
565	708300-4	Fuel Control, Jet	Hamilton Standard	118	73-11-11




ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
566	708300-5	Fuel Control, Jet	Hamilton Standard	118	73-11-11
567	708400-1	Fuel Pump	Argo-Tech	180	73-11-12
568	708400-2	Fuel Pump	Argo-Tech	180	73-11-12
569	708600-1	Fuel Control, Jet	Hamilton Standard	118	73-11-11
570	708600-2	Fuel Control, Jet	Hamilton Standard	118	73-11-11
571	708600-2	Fuel Control, Jet	Ham Standard DELTA	191	73-11-11
572	708600-5	Fuel Control, Jet	Hamilton Standard	118	73-11-11
573	708600-6	Fuel Control, Jet	Hamilton Standard	118	73-11-11
574	708600-7	Fuel Pump	Argo-Tech	118	73-11-11
575	710110	Fuel Control, Jet	Hamilton Standard	122	73-21-1
576	710777	Fuel Control, Jet	Hamilton Standard	103	73-21-2
577	710777	Fuel Control, Jet	Hamilton Standard	122	73-21-1
578	711000	Fuel Pump	Argo-Tech	203	73-11-04
579	711001-1	Fuel Pump	Argo-Tech	203	73-11-04
580	711001-10	Fuel Pump	Argo-Tech	203	73-11-04
581	711001-11	Fuel Pump	Argo-Tech	203	73-11-04
582	711001-12	Fuel Pump	Argo-Tech	203	73-11-04
583	711001-2	Fuel Pump	Argo-Tech	203	73-11-04
584	711001-3	Fuel Pump	Argo-Tech	203	73-11-04
585	711001-4	Fuel Pump	Argo-Tech	203	73-11-04
586	711001-5	Fuel Pump	Argo-Tech	203	73-11-04
587	711001-5	Fuel Pump	Argo-Tech	203	73-11-04
588	711001-6	Fuel Pump	Argo-Tech	203	73-11-04
589	711001-7	Fuel Pump	Argo-Tech	203	73-11-04
590	711001-9	Fuel Pump	Argo-Tech	203	73-11-04
591	711283-11	Fuel Control, Jet	Hamilton Standard	98	73-2-2
592	711283-12	Fuel Control, Jet	Hamilton Standard	98	73-2-2
593	711283-15	Fuel Control, Jet	Hamilton Standard	98	73-2-2
594	711283-16	Fuel Control, Jet	Hamilton Standard	98	73-2-2
595	711286-33	Fuel Control, Jet	Hamilton Standard	98	73-2-2
596	711286-36	Fuel Control, Jet	Hamilton Standard	98	73-2-2
597	711286-39	Fuel Control, Jet	Hamilton Standard	98	73-2-2
598	711286-41	Fuel Control, Jet	Hamilton Standard	98	73-2-2
599	711286-47	Fuel Control, Jet	Hamilton Standard	98	73-2-2
600	711286-50	Fuel Control, Jet	Hamilton Standard	98	73-2-2
601	711286-53	Fuel Control, Jet	Hamilton Standard	98	73-2-2
602	711286-55	Fuel Control, Jet	Hamilton Standard	98	73-2-2
603	711287-17	Fuel Control, Jet	Hamilton Standard	101	73-2-3
604	711287-18	Fuel Control, Jet	Hamilton Standard	101	73-2-3
605	711287-19	Fuel Control, Jet	Hamilton Standard	101	73-2-3
606	711287-20	Fuel Control, Jet	Hamilton Standard	101	73-2-3
607	711287-21	Fuel Control, Jet	Hamilton Standard	101	73-2-3
608	711287-22	Fuel Control, Jet	Hamilton Standard	101	73-2-3
609	711287-23	Fuel Control, Jet	Hamilton Standard	101	73-2-3
610	711287-24	Fuel Control, Jet	Hamilton Standard	101	73-2-3
611	711287-25	Fuel Control, Jet	Hamilton Standard	101	73-2-3
612	711287-26	Fuel Control, Jet	Hamilton Standard	101	73-2-3



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
613	711659 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
614	714810 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
615	714900-1	Fuel Pump	Argo-Tech	186	73-11-13
616	714900-2	Fuel Pump	Argo-Tech	186	73-11-13
617	714900-3	Fuel Pump	Argo-Tech	186	73-11-13
618	714900-4	Fuel Pump	Argo-Tech	186	73-11-13
619	714900-5	Fuel Pump	Argo-Tech	186	73-11-13
620	715001-29	Fuel Pump	Argo-Tech	264	73-11-01
621	715001-30	Fuel Pump	Argo-Tech	264	73-11-01
622	715001-31	Fuel Pump	Argo-Tech	264	73-11-01
623	715001-32	Fuel Pump	Argo-Tech	264	73-11-01
624	715001-33	Fuel Pump	Argo-Tech	264	73-11-01
625	715001-34	Fuel Pump	Argo-Tech	264	73-11-01
626	715001-35	Fuel Pump	Argo-Tech	264	73-11-01
627	715001-36	Fuel Pump	Argo-Tech	264	73-11-01
628	715001-37	Fuel Pump	Argo-Tech	264	73-11-01
629	718142 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
630	718800	Fuel Pump	Argo-Tech	203	73-11-04
631	718801-10	Fuel Pump	Argo-Tech	203	73-11-04
632	718801-11	Fuel Pump	Argo-Tech	203	73-11-04
633	718801-12	Fuel Pump	Argo-Tech	203	73-11-04
634	718801-5	Fuel Pump	Argo-Tech	203	73-11-04
635	718801-6	Fuel Pump	Argo-Tech	203	73-11-04
636	718801-7	Fuel Pump	Argo-Tech	203	73-11-04
637	718801-8	Fuel Pump	Argo-Tech	203	73-11-04
638	718801-9	Fuel Pump	Argo-Tech	203	73-11-04
639	720050	Fuel Control, Jet	Hamilton Standard	103	73-21-2
640	720100	Fuel Pump	Argo-Tech	203	73-11-04
641	720101-10	Fuel Pump	Argo-Tech	203	73-11-04
642	720101-11	Fuel Pump	Argo-Tech	203	73-11-04
643	720101-12	Fuel Pump	Argo-Tech	203	73-11-04
644	720101-6	Fuel Pump	Argo-Tech	203	73-11-04
645	720101-7	Fuel Pump	Argo-Tech	203	73-11-04
646	720101-8	Fuel Pump	Argo-Tech	203	73-11-04
647	720101-9	Fuel Pump	Argo-Tech	203	73-11-04
648	720300	Fuel Pump	Argo-Tech	203	73-11-04
649	720301-10	Fuel Pump	Argo-Tech	203	73-11-04
650	720301-11	Fuel Pump	Argo-Tech	203	73-11-04
651	720301-12	Fuel Pump	Argo-Tech	203	73-11-04
652	720301-6	Fuel Pump	Argo-Tech	203	73-11-04
653	720301-7	Fuel Pump	Argo-Tech	203	73-11-04
654	720301-8	Fuel Pump	Argo-Tech	203	73-11-04
655	720301-9	Fuel Pump	Argo-Tech	203	73-11-04
656	720389-27	Fuel Control, Jet	Hamilton Standard	98	73-2-2
657	720389-29	Fuel Control, Jet	Hamilton Standard	98	73-2-2
658	720389-35	Fuel Control, Jet	Hamilton Standard	98	73-2-2
659	720389-37	Fuel Control, Jet	Hamilton Standard	98	73-2-2



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
660	720398-10	Fuel Control, Jet	Hamilton Standard	98	73-2-2
661	720398-7	Fuel Control, Jet	Hamilton Standard	98	73-2-2
662	720398-8	Fuel Control, Jet	Hamilton Standard	98	73-2-2
663	720398-9	Fuel Control, Jet	Hamilton Standard	98	73-2-2
664	720399-10	Fuel Control, Jet	Hamilton Standard	101	73-2-3
665	720399-7	Fuel Control, Jet	Hamilton Standard	101	73-2-3
666	720399-8	Fuel Control, Jet	Hamilton Standard	101	73-2-3
667	720399-9	Fuel Control, Jet	Hamilton Standard	101	73-2-3
668	721000	Fuel Pump	Argo-Tech	203	73-11-04
669	721001-10	Fuel Pump	Argo-Tech	203	73-11-04
670	721001-11	Fuel Pump	Argo-Tech	203	73-11-04
671	721001-12	Fuel Pump	Argo-Tech	203	73-11-04
672	721001-7	Fuel Pump	Argo-Tech	203	73-11-04
673	721001-8	Fuel Pump	Argo-Tech	203	73-11-04
674	721001-9	Fuel Pump	Argo-Tech	203	73-11-04
675	722100	Fuel Pump	Argo-Tech	203	73-11-04
676	722101-10	Fuel Pump	Argo-Tech	203	73-11-04
677	722101-11	Fuel Pump	Argo-Tech	203	73-11-04
678	722101-12	Fuel Pump	Argo-Tech	203	73-11-04
679	722101-7	Fuel Pump	Argo-Tech	203	73-11-04
680	722101-8	Fuel Pump	Argo-Tech	203	73-11-04
681	722101-9	Fuel Pump	Argo-Tech	203	73-11-04
682	723300	Fuel Pump	Argo-Tech	260	73-11-05
683	723301-10	Fuel Pump	Argo-Tech	260	73-11-05
684	723301-11	Fuel Pump	Argo-Tech	260	73-11-05
685	723301-12	Fuel Pump	Argo-Tech	260	73-11-05
686	723301-7	Fuel Pump	Argo-Tech	260	73-11-05
687	723301-8	Fuel Pump	Argo-Tech	260	73-11-05
688	723301-9	Fuel Pump	Argo-Tech	260	73-11-05
689	724400-1	Fuel Pump	Argo-Tech	184	73-11-14
690	724400-2	Fuel Pump	Argo-Tech	184	73-11-14
691	726218 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
692	731229 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
693	734467 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
694	736802 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
695	737062 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
696	738200-101	Fuel Valve Transfer Float	H.R. Textron	97	28-27-01
697	738200-103	Fuel Valve Transfer Float	H.R. Textron	97	28-27-01
698	739400-103	Fuel Level Control Switch	H.R. Textron	83	28-21-04
699	739400-105	Fuel Level Control Switch	H.R. Textron	83	28-21-04
700	739400-107	Fuel Level Control Switch	H.R. Textron	83	28-21-04
701	739666	Fuel Control, Jet	Hamilton Standard	103	73-21-2
702	742511	Fuel Control, Jet	Hamilton Standard	103	73-21-2
703	742511-1	Fuel Control, Jet	Hamilton Standard	103	73-21-2
704	742522	Fuel Control, Jet	Hamilton Standard	103	73-21-2
705	743496-8	Solenoid Operated Valve	Valve Research / DELTA	194	73-00-00



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
706	743496-9	Solenoid Operated Valve	Valve Research / DELTA	194	73-00-00
707	743522	Fuel Control, Jet	Hamilton Standard	103	73-21-2
708	743522-1	Fuel Control, Jet	Hamilton Standard	103	73-21-2
709	743602-1	Fuel Control, Jet	Hamilton Standard	103	73-21-2
710	743602-2	Fuel Control, Jet	Hamilton Standard	103	73-21-2
711	743602-2	Fuel Control, Jet	Ham Std/DELTA	177	73-21-2
712	743602-3	Fuel Control Unit	Hamilton Standard	103	73-21-2
713	743602-4	Fuel Control Unit	Hamilton Standard	103	73-21-2
714	743602-5	Fuel Control Unit	Hamilton Standard	103	73-21-2
715	743801	Fuel Control, Jet	Hamilton Standard	122	73-21-1
716	743801-1	Fuel Control, Jet	Hamilton Standard	122	73-21-1
717	743802	Fuel Control, Jet	Hamilton Standard	122	73-21-1
718	743802-1	Fuel Control, Jet	Hamilton Standard	122	73-21-1
719	743802-2	Fuel Control, Jet	Hamilton Standard	122	73-21-1
720	743802-3	Fuel Control, Jet	Hamilton Standard	122	73-21-1
721	743802-4	Fuel Control, Jet	Hamilton Standard	122	73-21-1
722	743803	Fuel Control, Jet	Hamilton Standard	122	73-21-1
723	743803-1	Fuel Control, Jet	Hamilton Standard	122	73-21-1
724	743803-2	Fuel Control, Jet	Hamilton Standard	122	73-21-1
725	743803-3	Fuel Control, Jet	Hamilton Standard	122	73-21-1
726	743803-4	Fuel Control, Jet	Hamilton Standard	122	73-21-1
727	745608 (774205)	Fuel Heater	Pratt & Whitney	251	73-14-01
728	746529 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
729	749965 (774217)	Oil Cooler	Pratt & Whitney	248	79-22-01
730	752137 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
731	755280 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
732	758847 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
733	766342 (774203)	Fuel Valve Pressurizing & Dump	Pratt & Whitney	215	73-12-01
734	769606-11	Fuel Control Unit	Hamilton Standard	104	73-21-05
735	769606-12	Fuel Control Unit	Hamilton Standard	104	73-21-05
736	769606-13	Fuel Control Unit	Hamilton Standard	104	73-21-05
737	769606-14	Fuel Control Unit	Hamilton Standard	104	73-21-05
738	769606-15	Fuel Control Unit	Hamilton Standard	104	73-21-05
739	769606-15	Fuel Control Unit	Ham Standard DELTA	192	73-21-05
740	769606-16	Fuel Control Unit	Hamilton Standard	104	73-21-05
741	769606-5	Fuel Control Unit	Hamilton Standard	104	73-21-05
742	769606-7	Fuel Control Unit	Hamilton Standard	104	73-21-05
743	769606-8	Fuel Control Unit	Hamilton Standard	104	73-21-05
744	772969 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
745	772997 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
746	782267 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
747	786445 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
748	789644 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
749	789762 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
750	791288 (771345)	Fuel Heater	Pratt & Whitney	275	73-14-01
751	821249	Fuel Pump	Pratt & Whitney/Argo-Tech	94	73-11-1



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
752	821250	Fuel Pump	Pratt & Whitney/Argo-Tech	102	73-11-2
753	825500	Fuel Pump	Argo-Tech	203	73-11-04
754	825501-10	Fuel Pump	Argo-Tech	203	73-11-04
755	825501-11	Fuel Pump	Argo-Tech	203	73-11-04
756	825501-12	Fuel Pump	Argo-Tech	203	73-11-04
757	825501-8	Fuel Pump	Argo-Tech	203	73-11-04
758	825501-9	Fuel Pump	Argo-Tech	203	73-11-04
759	828300-1	Fuel Pump	Argo-Tech	182	73-11-15
760	828300-2	Fuel Pump	Argo-Tech	182	73-11-15
761	828300-3	Fuel Pump	Argo-Tech	182	73-11-15
762	828300-4	Fuel Pump	Argo-Tech	182	73-11-15
763	828300-5	Fuel Pump	Argo-Tech	182	73-11-15
764	835800	Fuel Pump	Argo-Tech	94	73-11-1
765	835900	Fuel Pump	Argo-Tech	102	73-11-2
766	899727-10	Pump, Power Rotary	Allied-Signal	105	49-31-01
767	899727-3-1	Pump, Power Rotary	Allied-Signal	105	49-31-01
768	899727-5-1	Pump, Power Rotary	Allied-Signal	105	49-31-01
769	899727-8-1	Pump, Power Rotary	Allied-Signal	105	49-31-01
770	899727-9-1	Pump, Power Rotary	Allied-Signal	105	49-31-01
771	9255	Pump	Chandler Evans	139	73-12-04
772	9255-03	Pump	Chandler Evans	139	73-12-04
773	9255-04	Pump	Chandler Evans	139	73-12-04
774	9255-05	Pump	Chandler Evans	139	73-12-04
775	9255-06	Pump	Chandler Evans	139	73-12-04
776	9255-07	Pump	Chandler Evans	139	73-12-04
777	9255-08	Pump	Chandler Evans	139	73-12-04
778	9255-09	Pump	Chandler Evans	139	73-12-04
779	9257	Pump	Chandler Evans	139	73-12-04
780	9257-01	Pump	Chandler Evans	139	73-12-04
781	9257-02	Pump	Chandler Evans	139	73-12-04
782	9257-03	Pump	Chandler Evans	139	73-12-04
783	9257-04	Pump	Chandler Evans	139	73-12-04
784	9257-05	Pump	Chandler Evans	139	73-12-04
785	9257-06	Pump	Chandler Evans	139	73-12-04
786	9257-07	Pump	Chandler Evans	139	73-12-04
787	9257-08	Pump	Chandler Evans	139	73-12-04
788	9295A4	Main Fuel Pump	Goodrich	298	73-16-02
789	9295A5	Main Fuel Pump	Goodrich	298	73-16-02
790	9297-01A3	Main Fuel Pump	Goodrich	298	73-16-02
791	9297-01A4	Main Fuel Pump	Goodrich	298	73-16-02
792	9297-01A5	Main Fuel Pump	Goodrich	298	73-16-02
793	9297-01A6	Main Fuel Pump	Goodrich	298	73-16-02
794	9452	Main Fuel Pump	Chandler Evens	113	73-1-1
795	9477	Main Fuel Pump	Chandler Evens	113	73-1-1
796	9477-A10	Main Engine Fuel Pump	Chandler Evens	113	73-1-1
797	9477-A11	Main Fuel Pump	Chandler Evens	113	73-1-1
798	9477-A12	Main Fuel Pump	Chandler Evens	113	73-1-1



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
799	9477-A13	Main Fuel Pump	Chandler Evens	113	73-1-1
800	9477-A14	Main Fuel Pump	Chandler Evens	113	73-1-1
801	9477-A8	Main Fuel Pump	Chandler Evens	113	73-1-1
802	9477-A9	Main Fuel Pump	Chandler Evens	113	73-1-1
803	9478	Main Fuel Pump	Chandler Evens	113	73-1-1
804	9478-A10	Main Fuel Pump	Chandler Evens	113	73-1-1
805	9478-A11	Main Fuel Pump	Chandler Evens	113	73-1-1
806	9478-A12	Main Fuel Pump	Chandler Evens	113	73-1-1
807	9478-A13	Main Fuel Pump	Chandler Evens	113	73-1-1
808	9478-A14	Main Fuel Pump	Chandler Evens	113	73-1-1
809	9478-A9	Main Fuel Pump	Chandler Evens	113	73-1-1
810	966595-1-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
811	966595-2-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
812	966595-3-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
813	966595-4-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
814	966595-5-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
815	966595-6-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
816	966595-7-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
817	966595-8-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
818	968870-1-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
819	968870-2-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
820	968870-3-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
821	968870-4-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
822	968870-5-1	Valve & Flow Divider Assembly	Allied-Signal	95	49-31-08
823	969900-10	Fuel Control Assembly	Allied Signal	161	49-32-01
824	969900-11	Fuel Control Assembly	Allied Signal	161	49-32-01
825	969900-12	Fuel Control Assembly	Allied Signal	161	49-32-01
826	969900-13	Fuel Control Assembly	Allied Signal	161	49-32-01
827	969900-14	Fuel Control Assembly	Allied Signal	161	49-32-01
828	969900-8	Fuel Control Assembly	Allied Signal	161	49-32-01
829	969900-9	Fuel Control Assembly	Allied Signal	161	49-32-01
830	AV16A1323B	Valve Shut-off	ITT	11	28-22-01
831	AV16A1323B-1	Valve Shut-off	ITT	11	28-22-01
832	AV16A1348B	Valve Shut-off	ITT	11	28-22-01
833	AV16B1736D	Fuel Gate Valve	ITT	15	28-1-1
834	AV16B1736D	Fuel Gate Valve	ITT/DELTA	126	28-1-1
835	AV16E1167C	Fuel Gate Valve	ITT	19	28-1-1
836	AV16E1261D	Fuel Gate Valve	ITT	21	28-22-02
837	AV16E1261D1	Fuel Gate Valve	ITT/DELTA	124	28-22-02
838	AV16E1261D-1	Fuel Gate Valve	ITT	21	28-22-02
839	EM487-3	Actuator Assembly	Vickers Electro	59	28-20-21
840	MA11A1061B	Actuator Assembly	ITT	173	28-20-05
841	MA11A1062B	Actuator Assembly	ITT	173	28-20-05
842	MA11A1200B	Actuator Assembly	ITT	173	28-20-05
843	PAC101	Pump and Control	Lucas	150	73-10-01
844	PAC101MK5	Pump and Control	Lucas	150	73-10-01
845	PAC101MK8	Pump and Control	Lucas	150	73-10-01



ID	Part Number	Component Description	Manufacturer	TFC Manual	ATA.
846	PAC102	Pump and Control	Lucas	152	73-10-06
847	PAC102MK4	Pump and Control	Lucas	152	73-10-06
848	PAC102MK4A	Pump and Control	Lucas	152	73-10-06
849	V3400-283 (743496)	Solenoid Valve	Valcor Eng	286	73-20-01
850	V3400-292 (769606)	Solenoid Valve	Valcor Eng / DELTA	195	73-20-02
851	V5000-40	Solenoid Shut-off Valve	Garrett / DELTA	196	49-30-67
852	V5000-40 (692545)	Solenoid Shut-off Valve	Allied-Signal	93	49-30-67
853	V5000-43	Solenoid Shut-off Valve	Garrett / DELTA	196	49-30-67
854	V5000-43 (692545)	Solenoid Shut-off Valve	Allied Signal	93	49-30-67